

Printing with Transfer Paper

Transfer images with a hot iron to virtually any surface – fabric, paper, wood, glass, canvas, metal and more.

1. Print , draw or paint on the white side of the transfer paper
NB. For use in inkjet printers only.
2. Working on a smooth, flat, surface with a pre heated dry iron place transfer paper, image side down on to your material and iron for approximately 1 minute. If using a heat press, press for 20-25 sec. If any areas haven't transferred onto the fabric re iron. You can not over iron.
3. Transfer paper must be peeled back while still hot to reveal your design.

For the best appearance, use transfer paper on a high thread count white cotton. You may create your own designs on transfer paper or add to a printed image using felt markers prior to ironing. If you require clear areas you can scratch away the white polymer with a stylus. Once ironed onto fabric you can further embellish with beading, stitching etc.



S&S
Creativity unlimited™